


Installation Guide



	L(in)	W(in)	H(in)	D(in)	A(in)	B(in)	X(in) min
EMPV-36EC01	36	21	2 5/16	2 1/8	33 7/8	19 5/16	1 31/32
EMPV-30EC02	30	21	2 5/16	2 1/8	28 3/4	19 5/16	1 31/32
EMPV-24EC03	23 5/8	20 1/2	2 5/16	2 1/8	22 1/16	19 5/16	1 31/32

Safety Distance



A: 30 inch

B: 1-31/32 inch mini

C: 13/16 inch mini

D: Air intake

E: Air exit 1/4 inch



Adjust the bracket position to suit for different work surface's thickness.

